

DRAIN FRESHENER

ACTIVE ODOUR NEUTRALISER

SCRUBB®

SO YOU DON'T HAVE TO.

SCRUBB Drain Freshener is a fast-acting liquid which neutralises odours from kitchen and bathroom wastes, leaving a clean, fresh scent in the pipework. It helps keep traps and waste lines fresh by dislodging everyday residues that contribute to smells.



- Cleans & deodorises
- Targets bad smells at source
- Use regularly to prevent odours

DIRECTIONS FOR USE:

Remove any debris from the plughole and flush approx. 1L of very hot water through the drain. Then pour 100 ml SCRUBB Drain Freshener directly into the waste and allow it to settle in the trap; avoid flushing through with large volumes of water for at least 30 minutes. Use weekly as part of routine maintenance, or more frequently in problem areas. Suitable for kitchen sinks, bathroom basins, showers and floor drains. Note: This is not a drain unblocker - for removing blockages and clogs, use SCRUBB Drain Unblocker or SCRUBB Hair Clog Remover.

WARNING:

Contains: Isotridecanol, ethoxylated. Causes skin irritation. Causes serious eye irritation. Keep out of reach of children. If medical advice is needed, have product container or label at hand. Wash hands thoroughly after handling. Wear eye protection/protective gloves. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical advice/attention.



SIZE	PRODUCT CODE	CASE QTY	PALLET QTY	BARCODE NO.
1L	B17SC C100	6	600	5037832347343

ASK ABOUT OUR
HAND CARE RANGE!



WWW.SCRUBBGLOBAL.COM

+44 (0)1779 871945 info@scrubbglobal.com Orca Global, Blackhouse Circle Peterhead, AB42 1BN